




# iFlight BLITZ MINI F4 Wiring Diagram



## DJI Digital Transmitters

Firmware Target:IFRC-IFLIGHT BLITZ F722  
 FC plug&play part and setup compatible to DJI Air Unit and Caddx Vista



● Please check your protocols, otherwise your DJI Radio won't input signals!  
 DJI Goggle protocol and Betaflight protocol has to match!  
 For lower signal latency use the SBus\_BAUD\_FAST protocol option on both ends.  
 For Betaflight Copy/Paste "set sbus\_baud\_fast=on" into your Betaflight Configurator CLI then hit enter.  
 Use "save" and hit enter to save the changes.  
 Defaults: sbus\_baud\_fast=off, Goggle protocol set to NORMAL.







● The DJI Plug&Play connector has a VBAT passthrough! Please remember, the DJI Air Unit can just handle voltage up to 4S! To fly up to 6S batteries, please use an additional BEC (Voltage regulator).






● For DJI O3 Air Unit, In to the Betaflight Configurator Cli, Set osd device to MSP "set osd\_device = MSP" Specify the serial port of msp displayport as 0 (the number in this place should be the serial port number minus 1): "set displayport\_msp\_serial = 0" then type "save" and exit

## Others Receivers

Identifier	Configuration/MSP	Serial Rx
USB VCP	<input checked="" type="checkbox"/> 115200	<input type="checkbox"/>
UART1	<input checked="" type="checkbox"/> 115200	<input type="checkbox"/>
UART2	<input type="checkbox"/> 115200	<input type="checkbox"/>
UART3	<input type="checkbox"/> 115200	<input type="checkbox"/>
UART4	<input type="checkbox"/> 115200	<input type="checkbox"/>
UART5	<input type="checkbox"/> 115200	<input type="checkbox"/>
UART6	<input type="checkbox"/> 115200	<input type="checkbox"/>




set serialrx\_provider=FPORT  
 set serialrx\_inverted=ON  
 set serialrx\_halfduplex=ON




## VTX/CAM


Identifier	Configuration/MSP	Serial Rx	Telemetry Output	Sensor Input	Peripherals
USB VCP	<input checked="" type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART1	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	VTX (IRC Tran)   AUTO
UART2	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled
UART3	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	VTX (IRC Transmitter)   AUTO
UART4	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Camera (R/Cam Protocol)   AUTO
UART5	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Beeper/LIDAR   AUTO
UART6	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	OSD (F/Sky Protocol)   AUTO



## LED/BUZZER



## Anti-Spark filter





## ESC




## GPS

Identifier	Configuration/MSP	Serial Rx	Telemetry Output	Sensor Input	Peripherals
USB VCP	<input checked="" type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART1	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART2	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART3	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART4	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART5	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO
UART6	<input type="checkbox"/> 115200	<input type="checkbox"/>	Disabled   AUTO	Disabled   AUTO	Disabled   AUTO



## Status indicator



Note: Each LED indicates the status of your flight controller.