

Startruss

机架组装示意图

Frame Assembly Guide


1. 顶板 x1
Top plate
2. 底板 x1
Bottom plate
3. 机臂 x8
Arm
4. 电机座 x4
Motor mount
5. 侧支撑杆 CNC x2
Side support rod CNC
6. 扎带固定块 CNC x2
F
7. 支撑块 x8
S
8. 支架 (分左右) CNC x2
Bracket CNC
9. 上盖 CNC x1
Upper plate CNC
10. 接收机座 TPU x1
Receiver Mount TPU
11. GPS座 TPU x1
GPS mount TPU
12. 接收机天线座 TPU x2
Receiver Mount TPU
13. 摄像头硅胶板 x2
Camera vibration dampers silicone
14. 保护外壳 尼龙 x1
Protective shell nylon
15. 摄像头外壳 尼龙 x1
Camera canopy nylon
16. M3*24沉头内六角螺丝 x5
M3*24 countersunk hex screw
17. M3*8沉头内六角螺丝 x40
M3*8 countersunk hex screw
18. M3*10沉头内六角螺丝 x7
M3*10 countersunk hex screw
19. M3*16沉头内六角螺丝 x5
M3*16 countersunk hex screw
20. M3*28内六角螺丝 x5
M3*28 hex screw
21. M3*14内六角螺丝 x22
M3*14 hex screw
22. M3*12内六角螺丝 x5
M3*12 hex screw
23. M3*10内六角螺丝 x10
M3*10 hex screw
24. M3*7内六角螺丝 x4
M3*7 hex screw
25. M4*8杯头内六角螺丝 x18
M4*8

26. M4*15内六角螺丝 x3
M4*15 hex screw
27. M2*7内六角螺丝 x10
M2*7 hex screw
28. M2*8内六角螺丝 x10
M2*8 hex screw
29. M3*5*50圆形网纹铝柱 x3
M3*5*50 Al.standoff
30. M3防松自紧螺母 x9
M3 lock nut
31. M3*8内六角螺丝 x13
M3*8 hex screw
32. M2防松自紧螺母 x5
M2 lock nut
33. M2*10沉头内六角螺丝 x3
M2*10 countersunk hex screw
34. 内六角塞打螺丝 $\phi 4$ *M3*6 x3
 $\phi 4$ *M3*6 hex shoulder screw
35. M2*3.5*42圆形网纹铝柱 x2
M3*3.5*42 Al.standoff
36. M3.2*6*10双通铝柱 x5
M3.2*6*10
37. M4*10内六角螺丝 x3
M4*10 hex screw
38. M2*5内六角螺丝 x7
M2*5 hex screw

附赠 Additional parts

1. 80*15集线管 x4
80*15 Motor wire protector
2. XT30G 黑色母头 x2
XT30G female connector black
3. 格纹硅胶电池防滑垫 x2
Battery pad
4. 格纹硅胶相机防滑垫 x2
Camera anti-slip pad
5. 通用贴纸V4 x1
Sticker V4
6. 双IPEX直头转SMA弯头内针转接线 x2
Dual IPEX to RP-SMA female adapter cable
7. XT90E-M公头 带线 x2
Dual IPEX To RP-SMA Female Adapter Cable
8. USB转接板 x2
USB adapter
9. 天空端TYPE-C 转SH1.0板 x2
Air unit TYPE-C to SH1.0 adapter board
10. 四线端子线 x2
4 Pin Cable
11. 20*400超纤皮电池轧带 x2
20*400 Battery strap
12. 20*500超纤皮电池轧带 x2
20*500 Battery strap
14. XT30U-F母头带线 x1
XT30U-F pigtail
15. XT30U-M公头带线 x1
XT30U-Male Power Splitter

相机套件 Camera Kit



机臂部分 Frame Arm

