




机架安装指引 Mach R5 Ultra Trainer (HD & Analog)




机架安装指引 Mach R5 Ultra Trainer (HD & Analog)




机架安装指引 Mach R5 Ultra Trainer (HD & Analog)

配件清单



安装螺丝清单

M3*8 mm 半圆头螺丝	顶板	x4
M3*25 mm 半圆头螺丝	飞塔	x4
M1.2*2.5 mm 半圆头螺丝	图传黄片	x1
M2*4 mm 半圆头螺丝	摄像头	x2
M3*14 mm 沉头螺丝	中板/铝柱	x4
M3*9 mm 沉头螺丝	中板	x2
M3 防松自紧螺母	飞塔	x4



机架安装指引 Mach R5 Ultra Trainer (HD & Analog)

完整装配效果





电设布局



①摄像头 ②飞塔 ③天线 ④桨叶 ⑤电机


Frame Assembly Instruction

Mach R5 Ultra Trainer (HD & Analog)



Frame Assembly Instruction

Mach R5 Ultra Trainer (HD & Analog)




Frame Assembly Instruction

Mach R5 Ultra Trainer (HD & Analog)

Accessories List



A1 Sharkfin




A2 Canopy



A3 Receiver Antenna Mount



A4 Retaining Part




A5 M3*23 Aluminum Standoff




A6 Motor Wire Shield Tube

Screw Installation List

M3 × 8 mm Button Head Screw	Top Plate		x4
M3 × 25 mm Button Head Screw	Stack		x4
M1.2 × 2.5 mm Button Head Screw	VTX Spring Contact		x1
M2 × 4 mm Button Head Screw	Camera		x2
M3 × 14 mm Countersunk Screw	Middle Plate/Aluminum Standoff		x4
M3 × 9 mm Countersunk Screw	Middle Plate		x2
M3 Self-Locking Nut	Stack		x4



B1 Arm




B2 Anti-Slip Pad



B3 Top Plate



B4 Middle Plate



B5 Bottom Plate

Frame Assembly Instruction

Mach R5 Ultra Trainer (HD & Analog)

Full Assembly View



Electronics Layout



① Camera ② Stack ③ Antenna ④ Propeller ⑤ Motor