

ProTek25 Pusher V1

机架组装示意图

Frame Assembly Guide

- | | | |
|-----|----------------------------------|-----|
| 1. | M2*5内六角螺丝
M2*5 hex screw | x21 |
| 2. | M2*8 内六角自攻螺丝
M2*8 hex screw | x7 |
| 3. | M2*8内六角螺丝
M2*8 hex screw | x2 |
| 4. | M2*7内六角螺丝
M2*7 hex screw | x8 |
| 5. | M2*4内六角螺丝
M2*4hex screw | x4 |
| 6. | M3*20六角螺丝
M3*20 hex screw | x1 |
| 7. | M3尼龙螺母
M3 Nylon nut | x1 |
| 8. | M2*16内六角螺丝
M2*16 hex screw | x4 |
| 9. | M2尼龙螺母
M2 Nylon nut | x8 |
| 10. | 图传/天线座打印件
Antenna/RX TPU | x1 |
| 11. | 14摄像头/裸狗一体底座
14 TPU cam mount | x1 |
| 12. | 20摄像头/裸狗一体底座
20 TPU cam mount | x1 |
| 13. | 电池固定座
Battery compartment | x2 |
| 14. | 保护罩
Whoop Body | x1 |
| 15. | 接收机盖子
Receiver Hatch | x1 |
| 16. | 顶板
Cover | x1 |
| 17. | 条形EVA棉
EVA Adhesive foam | x1 |

