

Chimera9 ECO

机架组装示意图

Frame Assembly Guide

- | | |
|-----------------------------------|-----|
| 1. 底板 | x1 |
| Bottom plate | |
| 2. 中板 | x1 |
| Counter plate | |
| 3. 顶板 | x1 |
| Top plate | |
| 4. 机臂 A | x2 |
| Arm A | |
| 5. 机臂 B | x2 |
| Arm B | |
| 6. 摄像头侧板 | x2 |
| Camera side plate | |
| 7. 摄像头硅胶侧板 | x2 |
| Camera vibration dampers silicone | |
| 8. 脚垫 | x4 |
| Arm guard | |
| 9. 图传天线座打印件 | x1 |
| Antenna mount TPU | |
| 10. 电源线+插头 | x1 |
| Power cable + plug | |
| 11. 侧板 | x1 |
| Side panels | |
| 12. T 型天线座打印件 | x1 |
| T-type antenna mount TPU | |
| 13. M2*6 内六角螺丝 | x5 |
| M2*6 hex screw | |
| 14. M2*12 内六角自攻螺丝 | x3 |
| M2*12 self-tapping hex screw | |
| 15. M3*20 圆形网纹铝柱 | x7 |
| M3*20 Al. standoff | |
| 16. M3*30 圆形网纹铝柱 | x3 |
| M3*30 Al. standoff | |
| 17. 3*5*8 三通铝柱 | x3 |
| 3*5*8 Double-pass Al. standoff | |
| 18. M3*11 内六角螺丝 | x18 |
| M3*11 hex screw | |
| 19. M3*30 内六角螺丝 | x5 |
| M3*30 hex screw | |
| 20. M3*12 内六角螺丝 | x5 |
| M3*12 hex screw | |
| 21. M3*16 内六角螺丝 | x5 |
| M3*16 hex screw | |
| 22. M3*8 内六角螺丝 | x14 |
| M3*8 hex screw | |
| 23. M2*8 内六角自攻螺丝 | x5 |
| M2*8 self-tapping hex screw | |

- | | |
|--------------------|----|
| 24. M1.6*6 内六角螺丝 | x5 |
| M1.6*6 hex screw | |
| 25. M3 防松自紧螺母 | x5 |
| M3 lock nut | |
| 26. 3*5*8 尼龙柱 | x5 |
| 3*5*8 Nylon column | |

附赠 Additional parts

- | | |
|---------------------------|----|
| 1. 集线管 | x4 |
| Motor wire protector | |
| 2. 格纹硅胶电池防滑垫 | x1 |
| Battery pad | |
| 3. MR30 接口 | x4 |
| MR30 Connectors | |
| 4. 20*300 超纤皮电池扎带 | x2 |
| 20*300 Battery strap | |
| 5. 前置 GPS 支架打印件 | x1 |
| Front GPS mount TPU | |
| 6. M3*10 内六角带垫螺丝 | x3 |
| M3*10 Wash head hex screw | |

